

Navimount RIB CLEAN- PEEL- STICK

**Important:** Please follow the mounting instruction to obtain optimum adhesion of the Navimount RIB



- Mark the area where you want to mount the Navimount RIB with a pencil or tape



- Carefully clean the surface of the inflated boat where you want to mount the Navimount RIB with a proper cleaning solvent
- Wait until the surface is dry
- Peel the paper from the 3M VHB



- Position the Navimount RIB exactly to the marked area
- once the Navimount RIB is mounted it will be very difficult to remove or reposition



- Bond strength is dependent upon amount of adhesive to-surface contact - therefore press firmly starting at the center with your fingers and apply if possible a weight until it's perfectly bonded. NOTE: At room temperature app. 50% of the ultimate strength will be achieved after 20 minutes, 90% after 24hrs and 100% after 72hrs



- Navilight models 041 and 341 can be mounted directly
- Navilight models 001, 010, 040, 305 and 340 require in addition the Navisafe converter Navimount / 960